



Monarch Homes Inc.

9914B – 113 Avenue

Grande Prairie AB T8V 1W7

P: 780.538.4026

info@monarchhomes.ca

F: 780.539.7063

www.monarchhomes.ca

Cabinet Adjustments

From time to time, your kitchen cabinets may require adjustments to ensure proper alignment and function. Keep a Phillips head and slotted screwdriver available to make these simple adjustments.

Decorative Hardware and Hinges

- Prior to changing decorative hardware, adjust all doors and drawers to ensure proper alignment.
- Your hardware can become loose from frequent use. Simply use the appropriate screwdriver to re-tighten any loose hardware
- Use the appropriate screwdriver to tighten any door hinges that might have come loose by turning the screw clockwise

Door Alignment and Function

- Doors can be adjusted up and down by slightly loosening the screws used to fasten the hinges to the face frame. Once the screws are loose, move the door to its proper location. Note that sometimes screws are hidden beneath a cap that will first need to be removed
- Most doors can be adjusted side to side to close or open gaps between doors. Adjust the screw typically found on the hinge arm that attaches the door to the face frame.
- Most doors can also be adjusted in or out. Adjust the screw that is typically found on the hinge plate towards the inside of the cabinet.

Drawer Alignment and Function

- Most cabinet brands use drawer slide hardware that is adjustable. Height can be adjusted on both sides by sliding the tab towards the back or front of the drawer.



Monarch Homes Inc.

9914B – 113 Avenue

Grande Prairie AB T8V 1W7

P: 780.538.4026

info@monarchhomes.ca

F: 780.539.7063

www.monarchhomes.ca

Adjustable Shelves

- Simply remove the shelf, remove shelf clips, and reposition.

Roll Out Tray

- Fully extend the tray then disengage the locking devices on the underside, Readjust, and reinstall the roll tray by pulling out the slides and then sliding the roll tray box back onto the slide until they engage.